








I



Ruige

I




RG-S29G-E V3

\$

Ruige





19






(

4





OT


OT





1	
2	
3	OT
4	

PE

PE






1 Console

2 Telnet/SSH
CLI

3 SNMP
CLI

4 WEB
WEB admin/admin

| Console



| Console



Console

CRT

```
Boot 1.2.9-5bb0801 (Build time: Sep 25 2014 - 10:26:15)
DRAM: 1 GiB
NAND: 512 MiB
Flash: 8 MiB
SETMAC: Setmac operation was performed at 2014-09-09 11:08:47 (version: 1.1.0)
Press RETURN to get started
```

3

Press RETURN to get started

```
*Nov 27 17:30:10: %DP-6-POWER_OK: Power 2 ok.
~ # *Nov 27 17:30:14: %DP-5-PROB: Board probing has completed.
*Nov 27 17:30:14: %DEV_MONITOR-6-DEVICE_INIT: master role init.
*Nov 27 17:30:15: %REDUNDANCY-6-STATES_CHANGE: Redundancy states changed: role master, state alone.
*Nov 27 17:30:15: %RG_SYSMON-5-WARMSTART: System warmstart
Press RETURN to get started
e>
```

“ Enter ”

CLI
VSU


6min

VSU

VSU

VSU

| Console



Console

CLI

Telnet/SSH

CLI

CLI

Ruijie> // :

Ruijie>en

Ruijie# //

Ruijie#config

Enter configuration commands, one per line. End with CNTL/Z.


Ruijie(config)# //

?


Console



CLI



| Console



11.X CLI

10.X

CLI

Ruijie#show version /show version slots / show cpu /show memory /show interface status /show ip route /show arp /show fan / show power /show temperature....

Ruijie#show run //

Ruijie(config-if-GigabitEthernet 1/1)#show this //

Ruijie#wr //

Ruijie#ping 8.8.8.8 // Ping

Ruijie#traceroute 8.8.8.8 // traceroute

Ruijie#telnet 192.168.3.254 // telnet

Ruijie#debug ip icmp //






Telnet



Telnet





RG-S29
RG-S29



RGOS 11.4(1)B12
RGOS 11.4(1)B12

.pdf
.pdf


S6220
11.X

10.X

S12000	S8600	S5750
S29G-E V3		



I



1 TFTP

2 UBOOT

PPT

1
2
3

bug

TFTP

1 PC TFTP Server PC S29G-E V3

2 S29G-E V3 TFTP Client TFTP ,
flash tmp tmp
Ruijie#copy tftp://192.168.1.1/S2910-NONE-
POE_RGOS11.4(1)B1_02160311_install.bin flash:/S2910-NONE-
POE_RGOS11.4(1)B1_02160311_install.bin
3 Upgrade upgrade

TFTP

TFTP

t

- www.ruijie.com.cn
- www.ruijie.com.cn/service.aspx
- support.ruijie.com.cn

- webchat.ruijie.com.cn
- 4008-111-000