





RG-S2910- 24GT4SFP-UP- H	24 10/100/1000M PoE/PoE+ 4 HPOE 4 1000M SFP	POE HPOE POE 1.XX 2.XX 90W 3.XX 60W
RG-PBOX-DC12	RJ45 POE DC12V	

HPOE
RG-PBOX-AC24


RG-S2910-24GT4SFP-UP-H
RG-PBOX-DC12
POE

POE











19




PBOX

(
4





PBOX




I



PBOX

PBOX
PBOX

M4*20mm



I



RG-PBOX

Data Out

PD

HPOE

1-4

Data&Power in

1m

18AWG

RG-

PBOX-DC12

CCD

C/CS

I






PBOX

OT

OT





1	
2	
3	OT
4	


PE

PE

I







RG-PBOX

Data out

Data&Power in

HPOE

RG-PBOX-DC12

PBOX



1 Console

2 Telnet/SSH
CLI

3 SNMP
CLI

4 WEB
WEB
admin/admin

| Console




PC


1

2

| Console



| Console




CLI



Ruijie>enable



| Console



11.X CLI

10.X

CLI

Ruijie#show version /show version slots / show cpu /show memory /show interface status /show ip route /show arp /show fan / show power /show temperature....

Ruijie#show run //


Ruijie(config-if-GigabitEthernet 1/1)#show this //

Ruijie#wr //

Ruijie#ping 8.8.8.8 // Ping




Telnet



Telnet







1 FTP

2 TFTP

FTP

3 USB

USB

A

FTP



- 1 FTP Server USB0 S6010 FLASH
 Ruijie(config)#ftp-server username admin
 Ruijie(config)#ftp-server password ruijie
 Ruijie(config)#ftp-server topdir tmp:/ -
 Ruijie(config)#ftp-server timeout 300
 Ruijie(config)#ftp-server enable
- 2 PC FTP Client FLASHFTP FTP PC
 S6010
- 3 PC FTP FTP Server
- 4 Upgrade USB

FTP


USB

USB
Upgrade

FTP

FTP
U

TFTP



- 1 PC TFTP Server PC S6010
- 2 S2910 TFTP Client TFTP , flash
tmp tmp
Ruijie#copy tftp://192.168.1.1/S2910_RGOS11.4(1)B3_02211500_install.bin
flash:/S2910_RGOS11.4(1)B3_02211500_install.bin
- 3 Upgrade upgrade

TFTP

USB

USB
Upgrade

TFTP

TFTP
U

TFTP

FTP

FTP

TCP

TFTP

UDP

TFTP

www.ruijie.com.cn

www.ruijie.com.cn/service.aspx

support.ruijie.com.cn

webchat.ruijie.com.cn

4008-111-000